

FLEX-GRIP

Strong, Flexible & Versatile Hoof Repair

A fast-curing, urethane-based adhesive for hoof repairs and gluing aluminum, steel, and composite shoes



*Designed for performance, strength, and versatility.
Available in Black and Tan for aesthetic matching.*

Set Time	Base Material	Packaging	Application
1 minute	Urethane	Durable 210mL cartridge	Forms strong, secure bonds to a variety of materials

Farriers Choice® Flex-Grip (Black & Tan) is a fast-setting, two-component polyurethane adhesive for hoof repair and shoe bonding. Odorless and non-sag, it forms a strong, secure bond with aluminum, steel, or composite shoes and is ideal for mild to extreme repairs. Available in two colors for aesthetic matching.

- **Fast & Easy to Use** – All-in-one solution with 30-second work time, 1-minute full set time.
- **Strong, Yet Pliable** – Provides lasting adhesion while allowing necessary flexibility.
- **Nail-Through Design** – Can be nailed through after curing for secure shoe attachment.
- **Color Options for Aesthetic Matching** – Available in Black and Tan to complement hoof appearance.
- **No Mess, No Waste** – Resealable, heavy-duty cartridge prevents leaks, preserves product, and allows multiple uses.

Resealable twist-off cap protects product between uses.

Cap and mixing tip fit into the cartridge one way only—to prevent cross contamination and eliminate material waste.

Mixing tip included with each cartridge!



Trusted by Farriers, Proven in the Field. Learn more at farrierschoice.com.

Farrier's Choice® offers a range of specialized adhesives, each tailored to address specific hoof care needs and designed to meet specific challenges faced by professional farriers, ensuring optimal hoof health and performance.



Farriers Choice® Flex-Grip

Quick-setting adhesive intended for mild to extreme hoof repairs and for gluing aluminum, steel, and composite shoes. Forms strong bond while remaining moderately pliable. Available in Black and Tan for aesthetic matching.

Set Time: 1 min. (30 sec. work time) **Base:** Urethane **Colors:** Black & Tan

TYPICAL PROPERTIES

	Part A	Part B	Mixed
Color - Black:	Amber	Black	Black
Color - Tan:	Amber	Beige	Beige
Viscosity @ 77°F, cps:	500 - 4,000	1,000 - 3,000	Paste
Weight per gallon, pounds:	9.38 - 9.78	8.4 - 8.7	-
Gel Time, [9.4 grams @ 77°F], seconds:	-	-	25 - 40
Shelf Life, sealed containers:	12 months	12 months	-

MIX RATIOS

	Parts By Weight	Parts By Volume
Part A:	100	1
Part B:	91	1

CURE SCHEDULE

Recommended Cure: 1 day at 77°F

* Typical cured properties were determined using the recommended cure schedule. Some differences in properties may occur with alternate or other cure schedules.

TYPICAL CURED PHYSICAL PROPERTIES

Hardness, Shore D [24 hr @ 77°F]:	55 - 70
Temperature Range:	-40°F to 149°F

STORAGE AND HANDLING

Store indoors in a warm (80°F-90°F), dry environment. This product is highly moisture-sensitive; keep containers sealed when not in use. After dispensing, blanket with nitrogen or dry air and reseal promptly. For industrial use only—handle with care. MSDS is provided with samples and available upon request. Prolonged skin contact may cause rash or dermatitis. Always use eye protection and appropriate gloves. If ingested, seek medical attention immediately.

DISCLAIMER

The information provided is based on our research and is considered accurate. However, no warranty, expressed or implied, is given.

**Look for other adhesives
in the Farrier's Choice line!**



Directions:

1. To open cartridge turn retaining nut 1/4 turn counter-clockwise.
2. Place cartridge into applicator gun, dispense material until two pistons are level or equalized.
3. Affix static mixer by aligning keyed interface. Use retaining nut to securely fasten mixer into cartridge.

Preserving unused product:

Replace dual plug and secure with cap.

Dispensing gun and mix tips (sold separately)

Use to dispense Farrier's Choice adhesives. Also works with other products that come in 210mL cartridges.



**For quality and consistency always use
original Quadro mixers!**



Distributed Exclusively by Castle Plastics
Supporting the hoof care industry for over 25 years.
978-534-6220 • farrierschoice.com



Made in the USA by Adhesive Engineering